



SOLID PRODUCTS, LLC
S O L I D D E C I S I O N

SOLID SURFACE CARE AND CLEANING

NORMAL EVERYDAY CLEANING

- Wipe the surface clean with a damp cloth or sponge.
- For everyday surface stains, clean with any general purpose cleaner.

REMOVING SURFACE STAINS, BURNS OR LIGHT SCRATCHES

- Scrub the surface in a circular motion with an abrasive cleaner, such as Soft Scrub®, and a wet, green Scotch-Brite® pad.
- To obtain the best results, repeat the previous step with a wet gray Scotch-Brite® pad.
- On dark colors, repeat with a wet white Scotch-Brite® pad.

REMOVING SCRATCHES

- Lightly and carefully sand the surface in a circular motion with 120-grit sandpaper.
- Repeat the previous step, using 220-grit sandpaper and finally 320-grit sandpaper.
- Scrub the surface in a circular motion with a wet green Scotch-Brite® pad and then repeat with a wet gray Scotch-Brite® pad. On dark colors, repeat with a wet white Scotch-Brite® pad.

PRESERVING A UNIFORM APPEARANCE

- Depending on the usage of your Solid Surface product, every 4 to 6 months scrub the entire surface of the product with a wet green Scotch-Brite® pad and an abrasive cleaner, moving in a circular motion. Repeat the above step with a wet gray Scotch-Brite® pad
- For darker colors, repeat with a wet white Scotch-Brite® pad.

GOOD PRACTICES

- Try not to cut directly on the surface of your Solid Products surface.
- Do not place hot pots or pans directly into a Solid Products sink. Our products can withstand temperatures up to 365°, but prolonged and extreme heat can cause a color shift.
- Quickly wipe strong acids, such as those found in drain cleaners. A few of these acids, when left on the surface, may cause whitening or discoloring of the surface.